

Use the following procedure for cleaning:

- a. Make sure the unit is turned "OFF" and disconnected from the electrical source.
- b. Drain the boiling tank.
- c. Fill boiling tank half full of water.
- d. Add cleaner.
(The amount of cleaner you use may need to be increased depending upon the kind and type of mineral deposits in your boiling tank.)
When Lumen II or another commercial cleaner is used, follow the directions on the package.
- e. Mix well.
- f. Fill boiling tank with water to the bottom of the water level gauge.
- g. Let solution stand overnight or until the mineral content softens. **UNDER NO CIRCUMSTANCES SHOULD THE CLEANING SOLUTIONS BE HEATED AND RUN THROUGH A STEAM STERILIZATION OR DISTILLATION CYCLE.**
- h. The next morning drain and rinse the boiling tank thoroughly.
- i. Be sure to refill the unit with water before beginning to distill water again.

AQUA CLEAN WIRING DIAGRAM

